

# Care, Clean-up and Maintenance:

## Inpro WT Shade Systems

---

Once installed, Roller Shades require very little care and maintenance. In order to prolong the life of your shades and keep them looking beautiful, some routine dusting may be required. Dust and dirt on your solar fabric can affect the color, the reflective properties, and even clog the space between the threads and effect the openness, and so removing it will be the main requirement in care.

### FABRICS

- Gently remove dust from the surface of the fabric by using a feather duster or soft cloth.
- Use a low suction vacuum with soft attachment for hard-to-reach areas or to remove dust between threads.
- Compressed air may be used to blow dust away from between threads.
- For spot cleaning, use a soft damp cloth. Mild detergent may be added for more stubborn spots. Shades should be fully extended and allowed to dry completely before being operated.

**Care Tip:** Gently rub a non-static dryer sheet over your shade material to help prevent the collection of dust.

- NEVER use harsh detergents or abrasive cleaners, such as alcohol, bleach or even baby wipes, which may damage, scratch or discolor the fabric.
- NEVER use a cloth which contains magnets, like many commercially sold dusting mitts. Magnets can damage certain types of fabric backings or cause motor malfunctions.
- NEVER clean windows with shades lowered. Always roll the shades up and away from the glass so that spray mist from glass cleaners does not damage the fabric.
- NEVER install shades in areas that are exposed directly to the elements. All WT Shade products are intended for INDOOR USE ONLY.
- NEVER rub fabric so hard as to damage the weave. Blotting is better.
- NEVER remove fabric from the shade tube without first contacting WT Shade. Removing the fabric may void your warranty

### HARDWARE

For general cleaning, use Antibacterial Fantastik® All Purpose Cleaner Heavy Duty with a clean, lint-free cloth and wipe clean. Repeat process if stains remain, and rinse with water if cleaning product residue remains. For all other cleaners and disinfectants, reference the product label to confirm use on plastic or powder coated metal material to avoid damage or discoloration.

Guide tracks may be lightly sprayed (inside) using silicone lubricant only. NEVER use petroleum-based lubricant.

NOTE: Any reference to a specific branded product does not constitute an endorsement by Inpro®. No long-term testing has been performed.